


(without price)

(KX-513)

# SEPT. 1997




# INDEX


# CASIO®

## TOP VIEWS


## Linear



## Back Light




## Switch




## Linear




# EXPLODED VIEW




## LINEAR




## BACK LIGHT




## SWITCH




## WAVEFORMS




① Q200 Collector




② IC200 Pins 19, 20




③ IC200 Pin 18




④ IC300 Pin 23




⑤ IC300 Pins 10, 11, 12




⑥ IC300 Pin 5




⑦ IC300 Pin 4




⑧ IC300 Pin 1




⑨ Q111 Collector




⑩ Q111 Base




⑪ IC700 Pin 17



⑫ IC700 Pin 14



⑬ Q806 Base



⑭ IC700 Pin 12